

## A61L-0001-0093/LCD

### LCD replacement for Fanuc A61L-0001-0093 9" CRT Display Adjustment Procedure

Most Fanuc controllers will automatically adjust the LCD display unit. However, sometimes screen may come on off-centered at first power on. Please follow the adjustment procedure below to correct the display.

*Note: You only need to do this adjustment once at initial installation. LCD unit will retain the settings even after power is turned off.*

- 1) There are 5 adjustments located on the side of the LCD unit. The only ones that are required for adjustment are "↑ -" , "↓ +" and "**Menu/Select**"
- 2) Press "**Menu/Select**" button. Then "↓ +" button to highlight "**Picture**" then press "**Menu/Select**". Press "↓ +" to highlight "**Clock**" then press "**Menu/Select**". Using "↓ +" button, increase the setting to **100**. Then press "**Menu/Select**"
- 3) Use "**H.Position**" and "**V.Position**" options together with "↑ -" , "↓ +" keys to align the screen to the center.

Questions? Email us at [service@kfasllc.com](mailto:service@kfasllc.com)