

8.38
ALARM 972
(NMI ALARM)

NMI has generated in a board other than the main CPU board.

Causes and Remedies

- 1) Any of option boards shown below may be faulty.
 - Option 1 board
 - Option 2 board
 - Option 3 board
 - Loader control board
- 2) The PMC control module may be faulty

```

SYSTEM ALARM                                B01-02

972 NMI OCUURRED IN OTHER MODULE

SLOT 02
915 SRAM PARITY : (2N+1)    <SUB } Indicates the slot No.
                                where an NMI occurred,
                                and the relevant mes-
                                sage.
    
```

Replace the board in the indicated slot.

CAUTION

When you change option 2 board, you must input data (parameters, programs, etc.) on sub side.
 When you change loader control board, you must input data (parameters, programs, etc.) on loader side.